





Spare parts for Log Splitter, LS5T-52		
NUMBER	PART DESCRIPTION	QUANTITY
1	SCREW ,M6*15	2
2	LIFT HANDLE	1
3	PLASTIC	1
4	SCREW,M8*20	4
5	HYDRAULIC CYLINDER	1
6	Piston	1
7	Piston seal	1
8	O-ring	1
9	Stud	4
10	Cylinder cover front	1
11	Seal	1
12	Piston rod weldment	1
13	Pin	1
14	Guding sleeve	2
15	Sliding pusher weldment	1
16	Spring guard (L)	1
17	Guid rod	2
18	Frame weldment	1
19	Retract Spring	2
20	Fixer	4
21	Screw ,M6*10	16
22	Spring washer, 6	8
23	Spring guard (R)	1
24	Bolt ,M8*12	5
25	Nut,M8	7
26	Bracket	1
27	Bolt ,m8*30	1
28	Gear Pump Housing-End	1
29	Sliding Sleeve	4
30	O-ring	2
31	Circlip	2
32	Pin ,B8*24	2
33	Steel Ball, 2.5	1
34	gear shaft	1
35	Gear	2
36	Gear housing plate	1
37	Bolt ,M5*185	3
38	Motor Cover-front	1
39	Washer	4
40	Spring washer, 5	5
41	Seal	1
42	Pin	1
43	Nut,M5	3
44	Motor assembly(motor、switch、capacitor、switch box、cable and plug、motor cover rear、shroud、fan)	1
45	Bolt ,M8*30	9
46	Spring washer, 8	11
47	Washer, 8	9
48	Pressure Limited Valve Spring	1
49	Steel Ball, 6	1
50	O-ring	2
51	Safety Valve Adjusting Screw	1
52	O-ring	1
53	Screw	1
54	Bolt , M5*8	1
55	Lever Guard	1
56	Screw ,M6*35	2
57	Control lever Assembly	1
63		1
64		1
58	Lever knob	1
59	Wheel Cover	2
60	Snap washer-shaft	2
61	Wheel	2
62	Wheel Bracket	1
65	Snap washer-shaft	1

A52改劈木机

66	Spring	1
67	Valve Rod	1
68	O-ring	1
69	Sliding Pressure Sensor Sleeve	1
70	O-ring	5
71	Valve Sleeve	1
72	O-ring	1
73	Cylinder cover-Rear	1
74	Spring	1
75	O-ring	1
76	Nut Plug	1
77	Copper Gasket	4
78	Nut cap	4
79	O-ring	1
80	Wing bolt	1
81	O-ring	1
82	Dipstick	1